



**NOTES**

- Install back-up rings and O-rings as shown in views.
- When installing continuous back-up rings, use the same technique and the same care used to install O-rings.
- When installing cartridge - be sure to torque to recommended value.

**INCLUDED COMPONENTS**

Part	Description	Quantity	View
500-001-018	O-Ring	1	D
500-001-021	O-Ring	2	A,B
500-002-020	O-Ring	1	C
515-002-018	Backup Ring	2	D
515-002-020	Backup Ring	1	C
515-002-021	Backup Ring	3	A,B

**USED WITH**

CVEV	CWEA	CWEG	CWEK	CWEL	DKFP	DKFR	DKFR8	DKFS	DOFP
DOFR	DOFR8	DOFS	DPCM	DPCN	DPCO	DPCP	DRCO	DRCR	DVCM
DVCN	DVCO	DVCP	FVDA	FVDA8	PSFB	PSFT	PVFA	PVFA8	PVFB
PVFD	RVED	RVED8	XNCA	XNOA					